

## Manual Sticker D/Z

## Package contents:

• Manual Sticker D/Z  $\times 1$ 

This user manual ×1



(\*1) Not usable for S-2000 strobe

How to attach

: Remove sticker base and put it around the EV Control Switch on D-2000/Z-240 back control panel as show in image below(a). Make sure that the sticker does not interfere operation of the dial knob (b).





Flash output: Actual flash output at each switch position is as below.

| Main Mode                    | EV. Control | Flash Output | G. N. | G. N.  |
|------------------------------|-------------|--------------|-------|--------|
| Switch                       | Switch      |              | Z-240 | D-2000 |
| FULL                         | Any         | 1            | 24    | 20     |
| <b>M</b> <sup>-0.5</sup> ▼-6 | -0. 5       |              | 21    | 17     |
|                              | -1          | 1/2          | 17    | 14     |
|                              | •           |              | 14    | 12     |
|                              | -2          | 1/4          | 12    | 10     |
|                              | •           |              | 10    | 8. 4   |
|                              | -3          | 1/8          | 8. 5  | 7. 1   |
|                              | •           |              | 7. 1  | 5. 9   |
|                              | -4          | 1/16         | 6. 0  | 5. 0   |
|                              | •           |              | 5. 0  | 4. 2   |
|                              | -5          | 1/32         | 4. 2  | 3. 5   |
|                              | •           |              | 3. 6  | 3. 0   |
|                              | -6          | 1/64         | 3. 0  | 2. 5   |

INON INC. 2-18-9 Dai, Kamakura, Kanagawa 247-0061 JAPAN Fax. +81(0)467-48-2178 E-mail support@inon.co.jp URL http://www.inon.jp/

As of June 2013