

INON

Simple

Reliable

High performance

Wireless

For easy and handy strobe shooting S-2000 Starter Kit SB

Shoe Base

The INON "S-2000" strobe supports wireless S-TTL Auto flash mode and provides substantial other high performance features in its compact body. The INON "Shoe Base Set" holds the S-2000 strobe directly to attach on compact digital camera housing enabling you to start simple and handy external strobe shooting. The S-2000 strobe gives you vivid underwater world with its substantial flash power. Let's start one-up underwater photography with INON S-2000 Starter Kit SB best suited to underwater shooters hesitating to add an external strobe to avoid oversized gears.

Combination example
with Panasonic TZ30



S-2000 Starter Kit SB

Package contents

● S-2000 strobe ● Shoe Base ● Z Joint

※ A digital camera and water-proof protector is not included in this package.



Compact high-performance S-2000 strobe

The S-2000 has successfully downsized its body while operated by 4x AA batteries and provides considerable features including Guide Number 20, beam angle 105°x95°, minimum recycle time approx. 1.5 sec (at FULL) etc. to support comfortable underwater shooting.



Next generation wireless S-TTL Auto mode equipped

Reliable and highly-accurate S-TTL Auto mode has been further evolved enabling wireless connection without using fiber optics to benefit you external strobe shooting with handy system.



Lighting from various angles

The Shoe Base Set (Shoe Base & Z Joint) supports vertical and horizontal strobe positioning adjustment depending on shooting conditions to support your creative intent of lighting.

The Starter Kit SB wireless connection compatible camera models (as of June, 2016)

Canon:

PowerShot D20 / S110 / G15 / S120 / G16 / G1 XMarkII / G7X / G7XMarkII

Olympus:

μ600 / SP-350 / μ720SW / μ725SW / μ750*2 / μ770SW / μ795SW / μ760 / SP-550UZ / SP-560UZ / μ780*2 / μ830*2 / μ850SW / μ790SW / μ1020 / μ1030SW / μTOUGH-6000 / μTOUGH-8000 / μTOUGH-6020 / μTOUGH-8010 / TG-610 / TG-810 / TG-820 / TG-1 / TG-2 / TG-830 / TG-835 / TG-3 / TG-4

Panasonic:

FS3 / FX35 / FX37 / FX40 / ZX1 / ZX3 / TZ5 / TZ7 / TZ10 / TZ20 / TZ30 / TZ35 / TZ40 / FT1 / FT2 / FT3 / FT4 / FT5

Fujifilm:

F100fd / F200EXR*2 / F80EXR*2 / F300EXR*2 / F550EXR*2 / F600EXR*2 / XQ1*2 / XQ2

※1 When using a Mount Base, wireless connection is not usable. Connect a strobe and housing with an INON Optical D Cable product.
※2 Depending on shooting situation, S-TTL Auto mode could be less accurate.



Canon PowerShot G15



Fujifilm F600EXR



Olympus μTOUGH-8000

INON

Simple

Reliable

Loose Proof

Wireless

For easy and handy strobe shooting S-2000 Starter Kit D4

The INON "S-2000" strobe supports wireless S-TTL Auto flash mode providing substantial high performance features in its compact body. Now we offer simple set-up with INON "Grip Base D4 Set" supporting loose-proof connection with an underwater housing to use the S-2000 strobe enabling you to start external strobe shooting. The S-2000 strobe gives you vivid underwater world with its substantial flash power. Let's start one-up underwater photography with INON S-2000 Starter Kit D4.

Combination example
with Canon G15




Next generation wireless S-TTL Auto mode equipped

Reliable and highly-accurate S-TTL Auto mode has been further evolved enabling wireless connection without using fiber optics to benefit you external strobe shooting with handy system.



Loose-proof lock system Grip Base D4

The Grip Base D4 widely supports any manufacturer's underwater housing. The SPS lock system (Patent. P) effectively prevents loosening during usage. The Grip Base D4 directly holds the S-2000 to support wireless S-TTL operation.



Unlimited Shooting Chances with Optional Parts

Add on Mount Base to hold an attachment lens or arm products will boost your shutter chance. This is real "Starter" kit where you do not have to change a strobe stay when you build-up your system.

S-2000 Starter Kit D4

Package contents

● S-2000 strobe ● Grip Base D4 ● Z Joint

※ A digital camera and water-proof protector is not included in this package.



The Starter Kit D4 wireless connection compatible camera models (as of June, 2016)

Canon:

IXY DIGITAL 300 / 300a / 400 / 450 / 500 / 600 / 700 / 70 / 80 / 1000 / 900IS / 10 / 90 / 910IS / 2000IS / 20IS / 25IS / 95IS / 920IS / 3000IS / 110IS / 210IS / 510IS / 220IS / 200F*1, PowerShot A10 / A20 / A30 / A40 / S30 / S40 / S45 / S50 / A60 / A70 / A80 / S11S / A75 / A85 / S60 / S70 / A95 / S80 / A540 / G7 / A570IS / A650IS / G9 / G10 / G11 / G12 / S90 / S95 / S100 / SX260HS / D20*1 / S110 / G15 / S120 / G16 / G7X / G7XMarkII

Olympus:

C-200Z / C-300Z / C-2020Z*2 / C-2040Z*2 / C-3000Z*2 / C-3030Z*2 / C-3040Z*2 / C-3100Z*2 / C-4040Z*2 / C-4100Z*2 / C-40Z / X-1 / X-2 / C-5050Z / μ-10 / μ-15 / μ-20 / μ-25 / μ-30 / C-740UZ / C-745UZ / C-750UZ / C-755UZ / C-5060WZ / C-760UZ / C-770UZ / X-3 / μ-40 / C-7070WZ / μ600 / SP-350 / SP-700 / μ710 / μ720SW*1 / μ725SW*1 / μ750*2 / μ770SW*1 / μ795SW*1 / μ760 / SP-550UZ / SP-560UZ / μ780SW*2 / μ830SW*2 / μ790SW*1 / μ850SW*1 / μ1020 / μ1030SW*1 / FE-360 / μTOUGH-8000*1 / FE-3010 / μTOUGH-6000*1 / μTOUGH-6020 / μTOUGH-8010 / TG-610 / TG-810 / TG-820 / TG-1 / TG-2 / TG-3 / TG-4

Panasonic:

FX01 / FX07 / FX30 / FX33 / FX35 / FX37 / FX40 / FS1 / FS2 / FS3 / ZX1 / ZX3 / TZ3 / TZ5 / TZ7 / TZ10 / TZ20 / TZ30 / TZ35 / TZ40 / FT1*1 / FT2*1 / FT3*1 / FT4*1 / FT5*1

Fujifilm:

F10 / F11 / F30 / F31fd / F40fd / F50fd / F100fd / F200EXR*2 / Z100fd / Z200fd / Z250fd / F80EXR*2 / F300EXR*2 / F550EXR*2 / F600EXR*2 / XQ1*2 / XQ2

Sony:

P100 / P150 / W1 / W5 / W7 / N1 / N2 / W170 / W300 / T77*1 / T700*1 / T90*1 / WX50 / WX100 / WX200

Nikon:

E2200 / E3200 / E4100 / E4200 / E5200 / E5900 / E7900

*1 When using a Mount Base, wireless connection is not usable. Connect a strobe and housing with an INON Optical D Cable product.
*2 Depending on shooting situation, S-TTL Auto mode could be less accurate.